




Seriové č.	Název součásti	
593 01	Screw	A
593 02	Strainer	
593 03	Suction support	
593 04	Guide bush	B
593 05	Screw	
593 06	Bearing bush	
593 07	Shaft	C
593 08	Diffuser Cover	
593 09	Impeller	
593 10	Diffuser	D
593 11	Sealing gasket	
593 12	Screw	
593 13	Intermediate support	E
593 14	Shaft ring	
593 15	Mechanical seal	
593 16	Screw	F
593 17	"O"ring	
593 18	Oil chamber cover	
593 19	Mechanical seal	
593 20	"O"ring	
593 21	Oil chamber	
593 22	"O"ring	
593 23	Deep groove ball bearing	
593 24	Motor rotor	
593 25	Motor pipe	
593 26	Motor stator	
593 27	"O"ring	
593 28	Deep groove ball bearing	
593 29	Screw	
593 30	Bearing seat	
593 31	"O"ring	
593 32	Screw	
593 33	Cable shield sleeve	
593 34	Cable cover	
593 35	Screw	
593 36	Outlet	
593 37	Plain washer	
593 38	Floating switch	
593 39	Pump pipe	

Department: Servis	Technical Officer:: Jaroslav Inderka	Drawn by: Petr Galuška	Reviewed by:		
 AQUACUP, s.r.o. Kollárova 969 Veselí nad Moravou www.aquacup.cz		Document type: Exploded view	Document Status:	Change: R00	
		Name, additional name: 5" AQ-TEC	Document number:		
			Date of issue: 8. 9. 2025	Lang: cz/en	Page: 1